


Brushless Jig Saw



Rubber Grip Handle

Ergonomic and slim design for maximum comfort and maneuverability

Battery Status Indicator

Dual Battery Release Buttons

Trigger Lock Button

Lock the trigger in ON or OFF position

Variable Speed Trigger Switch

Increase the speed by pressing the trigger

Tool Free Blade Change

For quick blade installation and removal

Saw Blade

Various Capacity Battery with Rubber Protection

From 2.0Ah to 5.0Ah battery capacities for different applications

Dust Exhaust Port

For connecting dust extractor

Brushless Motor

Professional Brushless Motor & Controller provide more power, higher efficiency and longer lifetime

4-Stage Pendulum Settings

For cutting a wide range of materials

Large Base Plate

Large base plate for better stability

Specifications

- Voltage : DC-20V
- No load speed : 0~2,600 SPM
- Stroke Length : 26 mm
- Cutting Capacity :
wood : 135 mm
steel : 10 mm
- Cutting Mode : 4-stage pendulum action

Simply Brushless



Ecopro Tools Corp.
Add: No.167, Sec.6, MinTsu Road, XinWu
Dist. Taoyuan City 32741, Taiwan
Tel: +886 3 4909599
E-mail: info@ecoprotools.com
http: //www.ecoprotools.com