

# 20V CG-DX0030 CG-DX0050

## Charger / Fast Charger

### CHARGER LED INDICATION

LED LIGHT DISPLAY STATUS	SYMBOL	CHARGING STATUS
	••••• Green light and red light are blinking	Battery damaged
	••••• Blinking green light Constant red light	Fully charged
	••••• Constant green light Constant red light	Charging
	••••• Blinking red light	Battery over heated



**CG-DX0030**  
Charger



**CG-DX0050**  
Fast Charger

Charger Model	Rated output current	Battery Capacity	Charging Time
CG-DX0030	4A	2.0Ah	40 min
		4.0Ah	80 min
		6.0Ah	120 min
		9.0Ah	180 min
CG-DX0050	6A	2.0Ah	26 min
		4.0Ah	48 min
		6.0Ah	72 min
		9.0Ah	108 min

The following battery packs can be charged by these chargers

Battery Model	Rated Battery Capacity (Ah)
BT-DX0030	2.0Ah
BT-DX0031	
BT-DX0050	4.0Ah
BT-DX0051	
BT-DX0060	
BT-DX0061	6.0Ah
BT-DX0090	
BT-DX0091	9.0Ah

### 基本規格

Rated voltage: AC 110-240V

Rated frequency: 50/60Hz

Rated input power:

CG-DX0030 : 100W

CG-DX0050 : 150W

Rated output voltage: DC 20V

Protection class:II

*Simply Brushless*



**Ecopro Tools Corp.**

Add: No.167, Sec.6, MinTsu Road, XinWu  
Dist. Taoyuan City 32741, Taiwan

Tel: +886 3 4909599

E-mail: info@ecoprotools.com

http://www.ecoprotools.com